## WONDER WHEEL

## Operating Instructions

C.P.U. Version ww1-08
Sound version ww5a
Mianual Revision • 10/27/2000

### WONDER WHEEL SENSOR ALIGNMENT

- > AFTER OPENING THE BACK DOOR, REMOVE THE BACK GRAPHICS. LOOKING FROM THE BACK, REMOVE THE BLUE TRIM PIECE FROM THE LEFT SIDE OF THE WHEEL.
- > FIND & DISCONNECT THE FLAT, WHITE CABLE WITH THE PHONE PLUG. THIS SHOULD STOP THE MOTOR.
- > NEXT LOCATE THE CONNECTOR FOR THE WHEEL SENSOR. IT SHOULD BE A 4-PIN MOLEX, WITH (3ea) WIRES. YOU WILL FIND; WHITE, RED, & RED/GREEN.
- > CONNECT YOUR METER. GROUND LEAD TO THE WHITE-WIRE, THE OTHER TO THE RED/GREEN.
- > LOOSEN THE NUT HOLDING THE SENSOR IN PLACE.
- > WITH THE REFLECTIVE TAPE NOT IN FRONT OF THE SENSOR YOU SHOULD GET AT LEAST 4 VOLTS DC. IT CAN GO TO 5 VOLTS DC.
- > WHEN YOU PUT THE TAPE IN FRONT OF THE SENSOR, YOUR READING SHOULD BE APPROACHING O VOLTS DC. Under . 2 vdc
- > FOLLOWING THIS PROCEDURE SHOULD FIX START & STOP PROBLEMS.

#### **DIPSWITCH SETTINGS**

Wonder Wheel has three banks of dipswitches labeled DS1, DS2, and DS3 that are used to program the game. Each bank of switches has 10 positions (Pos. #1-#10). The switches are located on Wonder Wheel's main controller board located behind the display panel in the back of the game.

x = closed or on position

o = open or off position

\*\*\* = default setting

B = BONUS SLOT (USE BONUS TICKET PATTERN)

#### **GENERAL TICKET TABLE**

DS	Pos	Pos #2	Pos #3	TICKET VALUE TABLE	yel (2.5")	red (5.5")	blue (4")	green (4")	blue (4.75")	red (5.5")	yel (2.5")	red (5.5")	green (4.75")	blue (4")	red (5.5")
	0	0	0	Α	В	8	15	20	10	5	В	8	10	15	5_
	X	0	0	В	В	5	10	15	8	3	В	5	8	10	3
	0	Х	0	С	В	8	15	20	10	5	В	8	10	15	5
	Х	Х	0	D	В	. 5	10	15	8	3	В	_5	8	10	_3
***	0	0	Х	Е	В	8	12	15	10	5	В	8	10	12	5
3	Х	0	Х	F	В	4	8	10	5_	2	В	4	5	8	2
CEC	0	Х	Х	G	В	3	8	10	5	2	В	3	5	8	2
	Х	Х	Х	Н	В	3	8	10	5	2	В	3	5	8	_2

(MEASUREMENTS TAKEN FROM OUTSIDE OF FACE PLATES (vertical))

ALTERNATE TICKET PATTERNS (IF DIPSWITCH BANK2, #8 IS ON)

7.		—	1101	<u> </u>											
DS1	Pos #1	Pos #2	Pos #3	TICKET VALUE TABLE	yel (2.5")	red (5.5")	blue (4")	green (4")	blue (4.75*)	red (5.5")	yel (2.5")	red (5.5")	green (4.75")	blue (4")	red (5.5")
<u> </u>	0	0	0	Α	В	0	0	0	0	0	В	0	0	0_	0
	Х	0	0	В	В	0	0	0	0	0	В	0	0	0	0
	0	Х	0	С	В	0	0	0	0	0_	В	0	0	0	0
	Х	Х	0	D	В	0	0	0	0	0	В	0	0	0	0
	0	0	X.	Е	В	0	0	0	0	0	В	0	0	0	0
	Х	0	Х	F	В	0	0	0	0	0	В	0	0	0	0
	0	Х	Х	G	В	1	2	3	2	1_	В	1	2	3	1_
	Х	Х	Х	Н	В	1	1	2	1	1	В	1	1	2	1

(MEASUREMENTS TAKEN FROM OUTSIDE OF FACE PLATES (vertical))

#### **BONUS TICKET TABLE**

DS1	Pos #4	Pos #5	Pos #6	BONUS VALUE TABLE	1st	2nd	3rd	4th	5th
	0	0	0	A	30	50	150	300	500
	X	0	0	В	20	40	80	160	320
	0	X	0	С	100	200	300	400	500
	Х	Χ	0	D	30	60	120	240	480
***	0	0	X	E	50	100	200	400	800
	X	0	Х	F	75	150	300	600	1200
	0	X	X	G	25	50	75	100	250
	Х	X	Х	Н	30	60	90	120	700

(The "1st" is the wheel sticker number, "2nd, 3rd, 4th, 5th" are the values of consecutive "hits" on the same bonus hole.)

#### ALTERNATE BONUS PATTERNS (IF DIPSWITCH BANK2, #8 IS ON)

DS1	Pos #4	Pos #5	Pos #6	BONUS VALUE TABLE		2nd	3rd	4th	5th
	0	0	0	· A		0	0	0	0
	X	0	0	В	0	0	0	0	0
	0	Х	0	С	0	0	0	0	0
	Х	Х	0	D	0	0	0	0	0
	0	0	Х	E	0	0	0	0	0
	Х	0	Х	F	0	0	0	0	0
	0	Х	Χ	G	5	10	15	20	50
	Х	Х	Х	Н	15	30	60	120	240

#### **BONUS COUNTDOWN TIME**

# | Pos | Pos | BONUS TIME | | O | O | 7 SECONDS | | X | O | 8 SECONDS | | O | X | 9 SECONDS | | \*\*\* | X | X | 10 SECONDS |

#### RESERVED SETTINGS (all off)

	Pos	Pos	
DS1	#9	#10	NOT USED
***	0	0	LEAVE OFF

#### BANK 2

#### **CONSECUTIVE MISSES TO INC. MULTIPLIER**

DS2	POS #1	POS #2	
	0	0	1 MISSES IN A ROW
	X	0	2 MISSES IN A ROW
***	0	Х	3 MISSES IN A ROW
	Х	Х	4 MISSES IN A ROW

#### WHEEL MOTOR SPEED

D	DS2 POS		POS #4	WHEEL MOTOR SPEED
***		0	0	8 RPM
		Х	0	10 RPM
		0	Х	12 RPM
		X	Χ	15 RPM

#### **MAXIMUM MULTIPLIER VALUE**

ſ	DS2 POS #5		POS #6	MAXIMUM TICKET MULTIPLIER				
	•	0	0	3				
*	**	X	0	5				
		0	X	7				
		Х	X	9				

#### ATTRACT MODE

DS2	POS #7	ATTRACT MODE
	0	NO ATTRACT MODE SOUNDS
***	Х	ATTRACT MODE MUSIC EVERY 3 MIN.

#### ALTERNATE TICKET AND BONUS PATTERNS


DS2	POS #8	ALTERNATE PATTERNS
*** 0		USE NORMAL PATTERNS
		USE ALTERNATE TICKET AND BONUS
	X	PATTERNS

BANK 3
FREE TICKET PER COIN INSERTED

DS3	Pos #1	Pos #2	Pos #3	FREE TICKETS PER COIN
XXX	0	0	0	NO FREE TICKETS
	Χ	0	0	ALWAYS PAY 1 TICKET
	0	X	0	ALWAYS PAY 2 TICKETS
	Χ	Х	0	ALWAYS PAY 3 TICKETS
	0	0	Х	ALWAYS PAY 4 TICKETS
ĺ	X	0	Χ	ALWAYS PAY 5 TICKETS
	0	Χ	Χ	ALWAYS PAY 6 TICKETS
	Х	Х	Х	ALWAYS PAY 7 TICKETS

#### RESERVED SETTINGS (all off)

DS3	Pos #4	Pos #5	Pos #6	Pos #7	Pos #8	Pos #9	Pos #10
***	0	0	0	0	0	0	0



HA willus


Rondon whole Bound

Unless Display bd. 0 0 ⊙ p2 0 0 Bara/Credit/Hin Display bd. N.A. NACTIONAL N.A. TOLERWICE 3190 JULE NONE PROMITE TO DESCRIPTION OF THE PROMITE TY: Horsin' Around Wiring Machine Company, Inc. BRAJING MAKE Seidel Amusement DATE REU, REUSSON RECORD AUTH ha\_uire2.sch

20124

91 1140

4 1 1-19



1,005 200 × 14.05 16.05 105 1105 1105 1105 1105 1105 2 5500 2 SEGA SEGA 2014 SECTION S 195 P 15 SEGG 15 SEGG 17 SEGG 18 SEGGG 18 SEGG 18 SEGGG 18 SEGG 18 S FRACTIONAL TRACTIONAL TRACTIONAL TO N.A. 2000000 TOLCHWICE DSPLIS DSPL 19 DSP1 17 DATE 7-27-98 -65 Horsin Around Display . . . None pressure at DATE REU REUISION RECORD ha\_dspl2.sch 4 HUB

HA DESPUB (Ticket) (R)

M6C-4106

MGC-9106

MGC-9106

配品 151 REBERER 高 랑의장의원원경기 图 28222828 SERRE 36 76 BUS 長春養養養養養養 長春養養養養養養養養養養養養養養養養養養養 BEERBERR BEERBERRERRERRER **国生成四年四月日本日日日日日日日日日**日 의리전의 회의 회의 3 610 3 810 619 4-24884884 대 위 및 12 2 2 의의저의의 전 의 의 의 의 의 의 의 의 의 의 의 의 의 의 의 A Paris 0010 1000 THE PARTY OF THE P 봉수절 三日 東京 . . . 3 第二章 4-11-부수로 문수의 1 CS 20 見な N.A. N.A. THE PROPERTY Z N - 1 N - 1 100k 4 장수를 일수 23 10-15-97 DREATING PAINTER I date 2010011 811 15 CH324 811 15 CH324 10 CH324 10 CH324 10 K C 10 MGC 17 KZ 2230 BUJ None appears as 0 - 4 Z 15 - 10 3140 100 p 200 p 100 p 22 Audio 東京市 見るな 100 HEU. - 6 113 DRS4481 BV: . PH 2001 mgc2 2 BENESON SECTION Section w plasino-1 sch 2 Other 4 HIDE

MGC-9106

MGC-9106