PINBALL GAME SET-UP

CAUTION: At least 2 people are required to move and maneuver game.


Use proper moving equipment & extreme care while handling. Pinball game is 260lbs (+/- 10).

Refer to Game Manual for further Game Set-Up Procedures (Sec. 1, Chp. 1) and other important information!

TOOLS REQUIRED: 5/8" Socket Wrench & Utility Knife




 Before opening box, lay the box flat on its side with "TRUCK THIS SIDE ONLY" facing the floor.



Slide game out using the
 Black Nylon Strapping as a
 handle.



3. Remove the Four (4) Identical Legs with Levelers from the carton and set aside. (SAVE! all packing materials and information sheets related to this pinball until Set-Up is complete.)



 At this point DO NOT CUT STRAPPING (You want to keep the Backbox secured in the down position). Loosen and remove the 8 Leg Bolts (use 5/8" Socket Wrench) and set aside.



5. Lift game into an **UPRIGHT POSITION** (Coin Door Facing Up).



6. Install FRONT LEGS using the bolts removed from Step 4. Secure tightly. Take care not to scratch the Black Finish on any of the Legs.



7. Carefully set the game down on the **FRONT LEGS**. Care should be taken...Game is heavy, two (2) people are recommended for this and the following step.



8. Using supports or two (2) people, prop the rear of the cabinet up and install **REAR LEGS**. Secure tightly.




9. Cut BLACK NYLON STRAPPING. CAUTION: Strapping will SNAP, protect your eyes! Use extreme care when using a utility knife or scissors.



 Lift the Backbox into the UPRIGHT POSITION (Ensure the cables do not get pinched).



 After the BACKBOX is in the UPRIGHT POSITION, locate the 5/16" HEX KEY. While inserted, rotate KEY with a 3/4 turn until latched & locked.




NOTE: KEYS are tied to the Shooter Rod* (if equipped) or taped to the Playfield Glass (if equipped with Auto Plunger Button). Remove keys. One (1) set of keys opens the Coin Door, the other set is used to unlock the Back Glass to gain access to the White Star Board System.



13. Open the Coin Door and pull the YELLOW HANDLE to the LEFT and at the same time pull up on the FRONT TOP MOLDING and remove. The

I remove. The GLASS can now be pulled out towards you and removed. TAKE CARE while moving; set glass on a safe surface.




ALWAYS STORE THE MANUAL & INFORMATION SHEETS INSIDE THE CABINET WHEN NOT USING.

14. Through the open Coin Door, remove the RETAINING RING at the rear of the CASH BOX and open. Remove the PINBALLS & the PLUMB BOB from the SPARE PARTS BAG.

(Save the other spare parts in cabinet). Install the **PINBALLS** by placing them on the playfield so they can roll into the Outhole **Ball Trough**.

15. Install the PLUMB BOB on the Hanger Wire & tighten the Thumb Screw. Loosening the Thumb Screw & lowering or raising the PLUMB BOB makes the Games Tilt Function more or less sensitive.



Remove the **PINBALL GAME MANUAL** (stapled to side of the left wall of the cabinet). Review Section 1, Chapter 1, which describes how to lift the playfield to access the Plumb Bob Tilt Assembly. The manual gives you all the important information you need to prepare for final set-up and other important information (such as Parts, Diagnostics, Schematics and more...).



SPI Part № 755-5310-00


PINBALL GAME SET-UP

CAUTION: At least 2 people are required to move and maneuver game. Use proper moving equipment & extreme care while handling. Pinball game is 260lbs (+/- 10). Refer to Game Manual for further Game Set-Up Procedures (Sec. 1, Chp. 1) and other important information!


TOOLS REQUIRED: 5/8" Socket Wrench & Utility Knife




1. Before opening box, lay the box flat on its side with "TRUCK THIS SIDE ONLY" facing the floor.



Slide game out using the Black Nylon Strapping as a handle.



3. Remove the Four (4) Identical Legs with Levelers from the carton and set aside. (SAVE! all packing materials and information sheets related to this pinball until Set-Up is complete.)



4. At this point DO NOT CUT STRAPPING (You want to keep the Backbox secured in the down position). Loosen and remove the 8 Leg Bolts (use 5/8" Socket Wrench) and set aside.



5. Lift game into an UPRIGHT **POŠITION** (Coin Door Facing Up).



6. Install FRONT LEGS using the bolts removed from Step 4. Secure tightly. Take care not to scratch the Black Finish on any of the Legs.



7. Carefully set the game down on the FRONT LEGS. Care should be taken...Game is heavy, two (2) people are recommended for this and the following step.



8. Using supports or two (2) people, prop the rear of the cabinet up and install REAR LEGS. Secure tightly.



9. Cut BLACK NYLON STRAPPING. CAUTION: Strapping will SNAP, protect your eyes! Use extreme care when using a utility knife or scissors.




10. Lift the Backbox into the **UPRIGHT POSITION** (Ensure the cables do not get pinched).



11. After the BACKBOX is in the UPRIGHT POSITION, locate the 5/16" HEX KEY. While inserted, rotate KEY with a 3/4 turn until latched & locked.



equipped) or taped to the **Playfield Glass** (if equipped with Auto Plunger Button). Remove keys. One (1) set of keys opens the Coin Door, the other set is used to unlock the **Back Glass** to gain access to the White Star Board System.



13. Open the Coin Door and pull the YELLOW HANDLE to the **LEFT** and at the same time pull up on the FRONT TOP **MOLDING** and remove. The

GLASS can now be pulled out towards you and removed. TAKE CARE while moving; set glass on a safe surface.



Retaining Clip


Cash Box contains Spare Parts Bag Manual

ALWAYS STORE THE MANUAL & INFORMATION SHEETS INSIDE THE CABINET WHEN NOT USING.

14. Through the open Coin Door remove the **RETAINING RING** at the rear of the CASH BOX and open. Remove the PINBALLS & the PLUMB BOB from the SPARE PARTS BAG.

> (Save the other spare parts in cabinet). Install the PINBALLS by placing them on the playfield so they can roll into the Outhole Ball Trough.

> 15. Install the PLUMB BOB on the Hanger Wire & tighten the Thumb Screw. Loosening the Thumb Screw & lowering or raising the PLUMB BOB makes the Games Tilt Function more or less sensitive.



Remove the PINBALL GAME MANUAL (stapled to side of the left wall of the cabinet). Review Section 1, Chapter 1, which describes how to lift the playfield to access the Plumb Bob Tilt Assembly. The manual gives you all the important information you need to prepare for final set-up and other important information (such as Parts, Diagnostics, Schematics and more...).



Stern™Pinball, Inc. © 2000 SPI Part № 755-5310-00